



An Equal Opportunity Employer

Southwest Florida Water Management District

2379 Broad Street, Brooksville, Florida 34604-6899
(352) 796-7211 or 1-800-423-1476 (FL only)
WaterMatters.org

Bartow Office
170 Century Boulevard
Bartow, Florida 33830-7700
(863) 534-1448 or
1-800-492-7862 (FL only)

Sarasota Office
6750 Fruitville Road
Sarasota, Florida 34240-9711
(941) 377-3722 or
1-800-320-3503 (FL only)

Tampa Office
7601 U.S. 301 North (Fort King Highway)
Tampa, Florida 33637-6759
(813) 985-7481 or
1-800-836-0797 (FL only)

Randall S. Maggard
Chair, Pasco

Jeffrey M. Adams
Vice Chair, Pinellas

Bryan K. Beswick
Secretary, DeSoto, Hardee,
Highlands

Ed Armstrong
Treasurer, Pinellas

H. Paul Senft, Jr.
Former Chair, Polk

Michael A. Babb
Former Chair, Hillsborough

John Henslick
Manatee

James G. Murphy
Polk

Kelly S. Rice
Citrus, Lake, Levy, Sumter

Joel Schleicher
Charlotte, Sarasota

Rebecca Smith
Hillsborough, Pinellas

Mark Taylor
Hernando, Marion

Michelle Williamson
Hillsborough

Brian J. Armstrong, P.G.
Executive Director

April 10, 2018

Set 1

TO: All Potential Respondents
RFB 1812 Load and Deliver Shell from Lake Panasoffkee Shell Spoil Area

FROM: Georgia Hudson, Procurement Specialist 2

SUBJECT: Response to Questions

QUESTION: In regards to the loading of the shell, when an order is placed, will it always be for several loads or just one (1) to two (2) at a time? Trying to figure out cost of bringing a loader to load material each time an order is placed.

ANSWER: Typically, the minimum number of loads is fifty (50) to one hundred (100) loads per order, which may be achieved by scheduling two (2) or more properties at the same time. It should not be for one (1) or two (2) loads at any given time.